

Head to ballast cable for HMI 12KW / 18KW - 15m

Reference: LHA-15CABLE18KW



- Connects the lamp head to ballast
- Length: 15m
- For HMI 12KW/18KW fixtures



Product description:

15m long head to ballast cable that connects the HMI Fresnel 12/18K / HMI PAR 12/18K lights to their electronic ballast. 7-pin male & female connectors.

Product features:

